

1



CLEAN



DRY



DUST REMOVER

2



REMOVE

3



4



PRESS

5





DISPLEX

INSTRUCTIONS FOR SAMSUNG

1



CLEAN



DRY



DUST REMOVER

2



3



4



5

